

INSTRUCTION MANUAL

Coleman Brands Pty. Ltd. has gone to every effort to ensure that your product is of superior quality and meets the highest standards for convenience, comfort and durability. If for any reason your AeroBed® product is not working properly you will be entitled to a replacement product of the same value in accordance with the warranty terms and conditions. Please note that you will be asked to return your product with your proof of purchase to the place of purchase for testing and if a fault cannot be found you may be charged a service fee.

Thank you for purchasing our AeroBed® product. You can expect premium quality, innovation and durability from every AeroBed® product available. You are about to enjoy the comfort of AeroBed® product, the finest alternative sleeping system available anywhere. It is your responsibility to read and always follow the safety, care and maintenance instructions for your new AeroBed® product. Always instruct and supervise others on the proper use, maintenance and safety of your bed.

SAVE THESE INSTRUCTIONS READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

IMPORTANT SAFETY INFORMATION AND WARNINGS

To reduce the risk of personal injury or damage to property when using any electrical product, basic precautions should always be followed, including the following:

IMPORTANT

- Preparation of your AeroBed® product requires no tools. Use of tools may damage your bed.
- Always operate the product from a power source of the same voltage, frequency, and rating as indicated on the product identification plate.

⚠ CAUTION

- Do not attempt to fit and operate an electric under blanket or heating pad on or under the mattress.
- Do not use the product for other than its intended use as described in these instructions. This product is intended for normal domestic household use only. The use of accessory attachments other than those recommended by the manufacturer may cause safety hazards.
- Do not use pump for more than 20 minutes. Unplug the pump when not in use.

IMPORTANT

- Do not attempt to use the supplied pump with any other product; do not attempt to operate this product with any other than the supplied pump.
- Always operate the product from a power source of the same voltage, frequency, and rating as indicated on the product identification plate.

⚠ CAUTION

- To reduce the risk of electric shock, **do not immerse or expose** the pump motor, flexible cord, or plug to rain, moisture, or any liquid or use the product near baths, basins, or other vessels containing water or other liquids, or when **standing in or on** damp or wet surfaces. If any electrical product falls into the water, **UNPLUG it immediately**; **DO NOT REACH INTO THE WATER.**
Important: Prior to reconnecting to the power supply, the product should be inspected by a qualified technician.
- Close supervision is necessary when any electrical product is used by or operated near children or infirm persons; do not leave the product unattended when in use; young children should be supervised to ensure that they do not play with the product.
- Do not operate any product with a damaged cord or plug, or after the product malfunctions, or is dropped or appears damaged in any manner. Do not attempt to disassemble, repair, or service the pump. No serviceable parts are contained inside. Contact Coleman Brands Pty. Ltd., ABN 74 091 681 195, Suite W2C1, 75-85 O'Riordan Street, Sydney Corporate Park, Alexandria, NSW 2015, Australia or call 1800 224 350 or + 61 2 8762 5000 for repair or servicing information.
- Do not use an extension cord. Plug the pump directly into the power outlet.
- Do not use outdoors.
- Unplug the pump from the power outlet before any routine cleaning or maintenance.
- Do not operate the pump in the presence of explosive and/or flammable liquid or fumes.
- When storing the pump, loosely coil the cord. Avoid wrapping the cord around the product.
- Do not abuse the cord of the pump. Never carry the pump by the cord or yank to disconnect from the power outlet; instead grasp the plug and pull to disconnect. Keep the cord away from heated sources.
- Place bed in a safe area before use, making sure that there are no sharp edges, steps, drops, or breakable items nearby. Use on flat surfaces only. Bed may tip over on uneven surfaces.
- Standing, jumping, or walking on the bed may result in injury and/or damage to the bed. Do not jump, stand, or walk on this bed. You can hurt yourself or damage the bed if you do.

SERVICING OF DOUBLE-INSULATED PRODUCTS


In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace.

INFLATION

NOTE: BED MUST BE AT ROOM TEMPERATURE PRIOR TO INFLATING OR IT MAY CAUSE AIR LEAKS.

Remove your AeroBed® product from its lightweight duffle bag. Keep bag for storage.

1. Place your rolled-up bed on the floor free of obstructions or sharp objects.
2. Make certain the Quick Air Release Valve located at the head of the bed is closed. If the Air Release Valve is open, close it by using 2 thumbs to push cover and snap into valve. Be careful to avoid pushing valve cover to the right or left as it snaps into the valve opening.




This is the closed position. Open Air Release Valve. Close Valve Using 2 Thumbs.

3. Remove AC pump and cord from protective plastic shipping wraps.
4. This product has a polarized attachment plug (one blade is wider than the other) as a safety feature. This plug will fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to defeat this safety feature.

IMPORTANT: Always operate the product from a power source of the same voltage, frequency, and rating as indicated on the product identification plate.

5. Remove protective plastic cap from the Quick Air Release Valve by turning counter clockwise. Open the protective rubber cap at the end of the pump. Press mouth of the pump into position on the Quick Air Release Valve and turn clockwise until it locks.
6. A one-quarter turn clockwise automatically starts inflation.
7. At approximately 60 seconds, a high pitch whine of the pump will signal the bed is inflated to full (firmest) capacity. Bed will not over-inflate.





8. Detach pump by turning counter clockwise. Lie on bed and check the firmness. If you want your bed to be softer, depress the button in the center of the valve. If the bed becomes too soft, reattach the pump and reinflate the bed until the desired level of firmness is achieved.

IMPORTANT: Be sure to close the protective cap after inflation.

DEFLATION AND STORAGE

1. Open the Quick Air Release Valve cover at the head of the bed to release the air.
2. Fold sides of bed into the center along its length. Tightly roll your bed towards the Quick Air Release Valve at the end of the bed.
3. Roll the bed completely until all air is expelled. When the bed is completely rolled, push the Quick Air Release Valve closed and locked for its next use.
4. Slide the duffel bag over your AeroBed® product. Store your bed and pump until its next use.



CARE AND MAINTENANCE

1. Inspect your AeroBed® product prior to each use.
2. Keep your AeroBed® product away from any sharp objects. Large cuts or snags may not be repairable and will not be covered by your warranty.
3. When not in use, store your AeroBed® product in a clean, dry place out of extreme temperatures.
Note: Bed must be at room temperature prior to inflating or it may cause air leaks.
4. In case of incidental damage to your bed, repair patches have been included. Please follow repair instructions carefully.

CLEANING

We recommend that you do not let the plush surface of your AeroBed® product get wet. Repeated exposure to water or other liquids may cause damage to the plush surface that will not be covered by your warranty. Should liquid come in contact with the plush surface, blot liquid dry and use a damp cloth to remove any stain. Let surface air dry completely. You may clean the PVC on the sides and bottom of your AeroBed® product with a mild dishwashing detergent or household cleaner. Do not use strong chemicals or other compounds. Allow your bed to air dry completely after cleaning and before storing.

CAUTION: To reduce risk of electric shock, **do not immerse** or **expose** the adaptor/charger, pump motor, or flexible cord to water, rain, or any other liquid, **or charge** the pump near baths, basins, or other vessels containing water or other liquids, or when **standing in or on** damp or wet surfaces. If any electrical product falls into water, or if water should accidentally enter the pump motor or adaptor/charger, **UNPLUG it immediately**; DO NOT REACH INTO THE WATER. **Important:** Prior to reconnecting to the power supply, the product should be inspected by a qualified technician.

LIMITED WARRANTY

EXPRESS WARRANTY

Coleman Brands Pty. Ltd. ("Coleman") warrants that this product will be free from defects in material and workmanship for the following periods: the pump and valve, one (1) year from the date of original purchase and the mattress, one (1) year from the date of original retail purchase. Coleman will, depending on the circumstances, refund, repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. To the extent permitted by law and subject to your non-excludable rights under the Australian Consumer Law (Schedule 2 to the *Competition and Consumer Act 2010* (Cth)) and the *New Zealand Consumer Guarantees Act*, which are not limited to a one (1) year period, this is your exclusive remedy for any breach of this limited warranty or for any other claims otherwise relating to this limited warranty.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits provided under this warranty are in addition to and do not affect purchaser's statutory rights under the Australian Consumer Law or other rights at law.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Please keep your proof of purchase documentation, such as the original sales receipt or the relevant credit card statement. Proof of purchase is required to obtain warranty performance. Coleman dealers, Coleman service centres, or retail stores selling Coleman® products do not have the right to alter, modify or in any way change the terms and conditions of this warranty. The warranty is valid only for products that are purchased new and unused in Australia and New Zealand, from Coleman or Coleman dealers or retailers.

WARRANTY EXCLUSIONS AND LIMITATIONS

THE AUSTRALIAN CONSUMER LAW PROVIDES CONSUMERS WITH CERTAIN 'CONSUMER GUARANTEES'. THESE GUARANTEES APPLY WHERE THE GOODS AND SERVICES COLEMAN SUPPLIES TO YOU ARE OF A KIND ORDINARILY ACQUIRED FOR PERSONAL, DOMESTIC OR HOUSEHOLD USE OR COST LESS THAN \$40,000, AND IN THE CASE OF GOODS, ARE NOT RE-SUPPLIED BY YOU. NOTHING IN THIS LIMITED WARRANTY EXCLUDES, RESTRICTS OR MODIFIES RIGHTS WHICH YOU HAVE UNDER THE AUSTRALIAN CONSUMER LAW IN RESPECT OF THE CONSUMER GUARANTEES AND ALL OF THE PROVISIONS IN THIS SECTION ARE TO BE READ SUBJECT TO THE AUSTRALIAN CONSUMER LAW.

This warranty does not cover: (a) normal wear of the product and/or its parts; (b) parts that are not genuine Coleman® parts, consumables, lost parts and accessories; (c) damage resulting from any of the following: negligent use or misuse of the product, commercial use of the product, use contrary to the operating instructions; disassembly, repair or alteration by anyone other than Coleman or Coleman service centre, the use of a part other than a genuine Coleman® part; or (d) acts of God, such as fire, flood, hurricanes and tornadoes.

To the extent permitted by the Australian Consumer Law, *the Competition and Consumer Regulation 2010* and the *New Zealand Consumer Guarantees Act*, Coleman's liability is limited, depending on the circumstances, to refund, replacement or repair of Coleman® products or components.

For the avoidance of doubt, any and all other warranties or conditions which are not guaranteed by the Australian Consumer Law, *the Competition and Consumer Regulation 2010* and the *New Zealand Consumer Guarantees Act* and which are not expressly included in this warranty as additional warranties or conditions are expressly excluded, including liability for incidental or consequential damages caused by the breach of any express or implied warranty or condition.

MAKING A WARRANTY CLAIM - RETURN TO COLEMAN FOR REPAIR

Take the product to an authorised Coleman retailer or Coleman service centre as soon as the warranty claim arises. You may locate the nearest authorised Coleman retailer or Coleman service centre by visiting www.coleman.com or calling 1800 224 350. Please ensure that you provide a written description of the problem with the product, together with your contact name, address and telephone number and proof of purchase.

Subject to the applicable consumer laws in your jurisdiction, you must pay for the costs of transporting the product, including packaging, freight and insurance costs, to an authorised Coleman retailer or Coleman service centre for warranty service. If the warranty claim is substantiated and accepted by Coleman, Coleman will at its cost, repair or replace any product or parts and return the product to you. Additionally, if the warranty claim is substantiated and accepted by Coleman, Coleman will reimburse you for the costs of transporting the product to an authorized Coleman retailer or Coleman service centre. Coleman reserves the right to seek reimbursement for any costs and expenses incurred for a warranty claim if the product is found to be in good working order.

Please call or write us with any comments or questions:

Coleman Brands Pty. Ltd.
Unit 5-6, 13 Lord Street,
Botany NSW 2019
Australia

Telephone: 1800 224 350

Email: customerservice@colemanaustralia.com.au
www.colemanaustralia.com.au